

VEHICLE BACK-UP CAMERA


WIRELESS SYSTEM

3.5" LCD MONITOR USER'S MANUAL

USB slot to recharge ipod, mp3 players, digital cameras, phones, and more!
(CHARGING ONLY)



Plugs into 12V cigarette socket for power



IMPORTANT

Thank you for purchasing the WINPLUS Vehicle Back-Up Camera Wireless System. This back-up camera system was designed to give additional convenience when driving or operating your vehicle. All parts needed to install and operate the system are included in this package.

For questions or installation issues regarding the Vehicle Back-Up Camera Wireless System, please contact WINPLUS at 866.294.9244 to speak to one of our installation specialist. You can also contact us via email at info@WINPLUSusa.com.

LCD TELEVISION

After the 3.5" LCD MONITOR has been on for a length of time, you will notice that the screen becomes warm. Please note that this is normal. Sometimes the screen might have some tiny bright or dark spots. Please note that this is normal.

CAUTION

To prevent scratches or damages to the LCD screen, do not knock or rub the surface with sharp or hard objects. Clean the screen with a soft cloth moistened with warm water and dry with a soft cloth. A mild soap may be used if the screen is extremely dirty. Do not use harsh or abrasive cleaners!

WARNING

NEVER USE 3.5" LCD MONITOR IF A PROBLEM SHOULD OCCUR.

Abnormal operations such as smoke, strange odor, no image, no sound, excessive sound, damaged casing, elements, cables, penetration of liquids or foreign matter, etc. can cause a fire or electrical shock. In such case, immediately turn off the power switch and then disconnect the power plug. After making sure that the smoke or odor has stopped, contact your dealer. Never attempt to make repairs yourself because this could be dangerous.

Do not insert liquids or foreign objects into the 3.5" monitor

Do not expose the monitor to rain or moisture.

Do not place flower vases, pots, cups, cosmetics, liquids such as water, etc on or around the Monitor.

Do not place metals, combustibles, etc on or around the Monitor.

SETTING MENU / FEATURES

POWER ON / OFF

This power button is for power ON / OFF the LCD monitor. The monitor will be connected to the wireless back-up camera automatically once you have powered the back-up camera. If you have not powered the back-up camera or there is no signal, the LCD monitor will appears in BLUE/ TV screen noises. BLUE/ TV screen noises will turn OFF automatically if not in use for 20 seconds. (Please note that this is normal.)



The rotate button will help change the orientation of the image on the monitor. Adjust the orientation depending on the mounting option used.

BRIGHTNESS

To adjust brightness, keep pressing the brightness button to the desired brightness setting of the monitor.

COLOUR

To adjust color, keep pressing the color button to the desired color setting of the monitor.

SOUNDS

Fixed sound volume (Please note that this monitor will not perform any sounds by itself.) The volume function will only work with an external audio output.

Allows you to plug in headphones for audio

USB SLOT

To recharge USB gadgets. (Please note that the USB slots is for charging your gadgets only.)

12V POWER PLUG

LCD monitor power output. Use either the 12 volt adaptor or Hard Wired provided for LCD monitor power.

AV INPUT

Composite AV input jack allows you to plug in other AV input from other components. (Composite AV cable is included)

TM & © 2007 WINPLUS

 AUSTRALIA: Unit 1, 991 Mowbray Street, Melbourne, VIC 3125. Tel: 61-3-9573-4133 Fax: 61-3-9573-4130
 HONG KONG: 2/F, 11, Tai Ping Corporation Plaza, 11 On-ful Street, Hong Kong. Tel: 852-2788-8821 Fax: 852-2788-8821
 HUNGARY: Unit 6, New Commerce Center, Ady Endre Road, Budapest, H-1052, Hungary. Tel: 36-1-440-71388 Fax: 36-1-440-71389
 U.S.A. & CANADA: 375 West Apple Street, Machi, Delaware, CA 96301. Tel: 1-800-838-8388 Fax: 1-800-838-8388
 PLEASE A COMPANY OF QUALITY! Email: info@winplususa.com OR VISIT US ONLINE AT: www.winplususa.com
 *All Right Reserved

WIN-13107C